

PERFORMANCE ENGINE LEAD KITS

How to correctly measure NGK ignition lead lengths:

Distributor/Coil End

Spark Plug End

